

Safety Zone

Using Portable Fire Extinguishers in Healthcare Facilities

According to recent statistics from the <u>National Fire Protection Association (NFPA</u>), between the years 2011 and 2015 fire departments in the U.S. responded to an estimated 5,750 structure fires in healthcare properties each year. These fires led to an average of 157 civilian injuries and around \$50 billion in property damage. As the goal of healthcare facilities is to promote health and well-being, it's vital that providers ensure the safety and security of the building for both the patients and the employees.

Healthcare facilities are usually public buildings that can contain offices, restrooms, waiting rooms, dining rooms, patient rooms, and many other common spaces. These types of public facilities have portable fire extinguisher requirements governed largely by NFPA 10 Standard for Portable Fire Extinguishers.

Updates to Portable Fire Extinguisher Standards for Healthcare Facilities

However, there are some special and unique features healthcare facilities possess which necessitate specific requirements for portable fire extinguishers. In September of 2017, updates were made to the NFPA's 99 Healthcare Facilities Code 2018 and NFPA 101 Life Safety Code 2018 which affected the way these facilities utilize portable fire extinguishers onsite.

The 2018 updates to NFPA 99 lists specific requirements regarding the types of fire extinguishers used in particular areas within healthcare facilities. Updates to NFPA 101 affects wall-mounted fire extinguishers, ensuring they comply with accessibility standards under the Americans with Disabilities Act (ADA).

Some of the specific portable fire extinguisher standards in healthcare facilities include:

- The use of non-ferrous/non-magnetic fire extinguishers in magnetic resonance imaging (MRI) equipment and associated rooms. The extremely powerful magnets used in MRI equipment can make a deadly flying missile of even very large, heavy objects that are attracted to magnets (like a steelbody fire extinguisher), so only non-magnetic objects are permitted in the vicinity of MRI suites.
- Type K portable fire extinguishers must be provided in areas where there is potential for a fire involving combustible cooking media, such as vegetable oils, animal oils or fats. Since many healthcare facilities contain integral kitchens, this long-established kitchen standard is now referenced as healthcare specific standards. Typically, automatic fire suppression systems will also be required to protect the actual cooking appliances in addition to the type K portable extinguishers.
- Telecommunications entrance facilities and equipment rooms for electronic health records must be provided with clean agent portable fire extinguishers. *Clean agent* is defined as "electrically nonconductive, volatile, or gaseous fire extinguishant that does not leave a residue upon evaporation." Dry-chemical and water-mist fire extinguishers can damage sensitive electronic equipment in these areas. Additionally, operating rooms must be provided with water-mist or clean agent portable fire extinguishers.

Wall-mounted portable fire extinguishers must now not protrude from the wall surface on which they
are mounted more than four and a half inches if the extinguisher is below 38 inches from the floor. If
the extinguisher is above 38 inches from the floor, it should protrude no more than four inches from
the wall. This applies whether the fire extinguisher is mounted directly to the wall or is in a cabinet.
Many facilities find they need to install recessed cabinets in the wall to meet this new (2017)
requirement of NFPA 99. There is at least one fire extinguisher manufacturer that is now making
"flattened" profile extinguishers specifically to meet this requirement.

In all cases, employees who are authorized or expected to use extinguishers should be trained on how and when to use portable fire extinguishers, with periodic refresher training. Personnel in the facility should be familiar enough with the extinguishers to know how to remove them from their mountings, remove the safety pins and actuate the extinguishers.

Properly Using Portable Fire Extinguishers in Healthcare Facilities

Our infographic below shares some helpful tips on the proper use of portable fire extinguishers in healthcare facilities and other public buildings.



For additional information and resources on this topic and other safety and risk management subjects, visit the AmTrust Loss Control website: <u>https://amtrustfinancial.com/loss-control</u>

AmTrust distributes this e-newsletter as a service for its customers. It is provided in the spirit of professionals sharing their work with each other. The information provided in this document is intended for use as a guideline and is not intended as, nor does it constitute, legal or professional advice. It is not intended to provide authoritative answers to safety and health questions. AmTrust does not warrant that adherence to, or compliance with, any recommendations, best practices, checklists or guidelines will result in a particular outcome. Before using the information here, the accuracy and appropriateness of the information to your specific situation should be verified by a person qualified to assess all the factors involved.

CONTACT INFO:

| PHONE: | 888.486.7466 ext. 363275 |
|--------|-----------------------------|
| WEB: | www.amtrustnorthamerica.com |
| EMAIL: | AskLC@amtrustgroup.com |

MAILING ADDRESS: AmTrust North America 2605 Enterprise Road, Suite 290 Clearwater, FL 33759